

MANUAL BRAKE ADJUSTMENT

- I will pull on the slack adjuster to determine the direction of the
 S-Cam Shaft movement during a brake application
- 2. Push Lock Collar in with 9/16 wrench, and turn the nut to make S-Cam Shaft turn in the same direction as it does in a brake application until snug
- 3. Pull slack adjuster to make sure there is no movement
- 4. Back off nut approximately 1/3 of a turn
- 5. Check push-rod travel- Confirm ½ to ¾ of an inch
- 6. I will then make sure lock collar is out

